

Marca	Modelo	Serie	Desde Hasta	Aire	Habitaculo	Aceite	Combustible
TOYOTA	4 Runner	4 Runner D 2800 L, SL	0000-00-00 - en adelante			OL462	GS140
TOYOTA	Avensis	Avensis 2.0	0000-00-00 - en adelante	AR1726PM	TH984	-	-
TOYOTA	Avensis	TD 16V 2.0 D-4D - 1CDFTV, CDT220	0000-00-00 - en adelante	-	-	-	GS103
TOYOTA	Avensis	Wagon 2.0 D-4D - 1CD-FTV	0000-00-00 - en adelante	-	-	-	GS103
TOYOTA	Camry	Camry GL	0000-00-00 - en adelante	AR428PM	-	OL501	-
TOYOTA	Carina	Carina 1,8 2,0	0000-00-00 - 1994-01-01	AR875PM	-	OL472	-
TOYOTA	Celica	Celica	1980-01-01 - 1981-12-01	-	-	OL472	GS103
TOYOTA	Celica	Celica NAFTERA 2.0i	1980-01-01 - 1981-12-01	-	-	OL501	-
TOYOTA	Century	Century 3,0, 3,4 V3 - V4 - VU4	1977-01-01 - 1981-03-21	-	-	OL462	GS193
TOYOTA	Corolla	Corolla 1,8 Xei	2008-01-01 - en adelante	AR1728PM	TH969	-	-
TOYOTA	Corolla	Corolla GLS, SE 1,6 2TB	1980-01-01 - 1980-03-25	-	TH969	OL501	GS193
TOYOTA	Corolla	Corolla IX 2.0	2004-01-01 - en adelante	AR1727PM	-	-	-
TOYOTA	Corolla	Corolla 1200	1978-01-01 - 1983-03-20	-	-	OL472	-
TOYOTA	Corolla	Corolla 1300 DX 4K	1980-01-01 - 1980-03-25	-	-	-	GS193
TOYOTA	Corolla	Corolla 180 Nafta, 160 NAFTA 1.6, 1.8	0000-00-00 - en adelante	AR875PM	-	OL501	-
TOYOTA	Corolla	Corolla GL 1,6 2T	1980-01-01 - 1980-03-25	-	TH969	OL501	GS193
TOYOTA	Corolla	Corolla GLS, Sprinter, SE 1,8 3T	1980-01-01 - 1981-03-22	-	TH969	OL501	GS193
TOYOTA	Corolla	Corolla GLS, Sprinter, SE, S/W 1,8 Twin. Carb.	1982-01-01 - 1986-03-26	-	TH969	OL501	GS193
TOYOTA	Corolla	Corolla IX verso 1,8 16v VVTi	2008-01-01 - en adelante	AR1726PM	TH969	-	-
TOYOTA	Corolla	Corolla TRD	0000-00-00 - 2000-03-25	-	TH984	-	GS193
TOYOTA	Corolla	Corolla XEI 1.8	2000-01-01 - en adelante	-	TH969	OL479	-
TOYOTA	Corolla	Corolla XLI/XEI 1.8 16V	1998-01-01 - en adelante	-	TH985	OL501	-
TOYOTA	Corolla	Wagon - Compact 2.0 D-4D - 1CD-FTV	2000-01-01 - en adelante	-	-	-	GS103
TOYOTA	Corona	Corona	0000-00-00 - en adelante	AR875PM	-	OL472	-
TOYOTA	Corona	Corona GL Turbodiesel 2.0	2000-04-01 - en adelante	-	-	-	GS140
TOYOTA	Cressida	Cressida 2,6 4M-E	0000-00-00 - 2000-03-20	-	-	OL462	-
TOYOTA	Cressida	Cressida DX 1,8 3T	1980-01-01 - 1981-03-22	-	TH969	OL472	GS193
TOYOTA	Cressida	Cressida GL, GLE 2,4 22R	1976-01-01 - 1986-04-01	-	-	OL462	GS193
TOYOTA	Cressida	Cressida L, GL, GLE, S/W 2,0 21R	1981-01-01 - 1986-03-22	-	TH969	OL462	-
TOYOTA	Cressida	Cressida L, GL, S/W 2,0 18R	1976-01-01 - 1981-01-01	-	TH969	OL472	-
TOYOTA	Dyna	Dyna 150, 300 2,8 D	0000-00-00 - en adelante	AR2045	-	OL462	GS140
TOYOTA	HI-ACE	HI-ACE 1600 12R	1976-01-01 - 1982-03-22	-	-	OL472	-
TOYOTA	HI-ACE	HI-ACE 1800 2Y	2000-03-23 - en adelante	-	-	OL472	-
TOYOTA	HI-ACE	HI-ACE 2000 18R	1980-01-01 - 1981-03-22	-	-	OL472	-
TOYOTA	HI-ACE	HI-ACE 2000 1RZ	2000-03-30 - en adelante	-	-	OL469	-
TOYOTA	HI-ACE	HI-ACE Diesel	1979-01-01 - 1981-03-21	-	-	OL462	GS140
TOYOTA	HI-ACE	HI-ACE Diesel	1982-01-01 - 1986-03-26	-	-	OL462	GS140
TOYOTA	HI-ACE	HI-ACE Diesel	2000-03-29 - en adelante	-	-	OL462	GS140
TOYOTA	HI-LUX	HI-LUX 2,4 - 2,8 TD	2015-01-01 - en adelante	AR1741PM	TH2027	OL479	-
TOYOTA	HI-LUX	HI-LUX 1600 12R	2000-03-19 - en adelante	-	TH984	OL472	-
TOYOTA	HI-LUX	HI-LUX 1800 2Y	2000-03-23 - en adelante	-	TH984	OL472	GS193
TOYOTA	HI-LUX	HI-LUX 2000 18R-3Y	2000-03-19 - en adelante	-	TH984	OL472	GS193
TOYOTA	HI-LUX	HI-LUX 2000 3Y (4WD)	2000-03-24 - en adelante	AR1350	TH984	OL469	-
TOYOTA	HI-LUX	HI-LUX 2200 Diesel	1979-01-01 - 1985-03-25	AR1350	TH984	OL462	-
TOYOTA	HI-LUX	HI-LUX 2400 Diesel 2L	2000-03-23 - en adelante	-	TH984	OL462	GS140
TOYOTA	HI-LUX	HI-LUX 2400 Diesel	0000-00-00 - en adelante	AR1350	TH984	OL462	GS140
TOYOTA	HI-LUX	HI-LUX 2400 T. Diesel 4WD 2.4 TD, 2L-T	0000-00-00 - 2002-01-01	-	TH984	-	GS103
TOYOTA	HI-LUX	HI-LUX 2800 Diesel 4 x 4 - 4 x 2 L4 aspiración natural	2000-04-05 - en adelante	AR1350	TH984	OL462	GS140
TOYOTA	HI-LUX	HI-LUX Nueva Diesel 3,0 SL	2001-01-01 - en adelante	AR2029	TH984	-	EGSO204
TOYOTA	HI-LUX	HI-LUX Nueva Turbo Diesel 3,0 1K 2T	0000-00-00 - en adelante	AR2029	TH984	-	EGSO204
TOYOTA	HI-LUX	HI-LUX TD, Tdi 2.5, 3.0	2005-06-01 - en adelante	AR2035	TH984	OL479	EGSO204
TOYOTA	Ind. Equipment	Autoelevadores	0000-00-00 - en adelante	AR2121	-	-	-
TOYOTA	Land Cruisier	Land Cruisier 4,2 2F 6 Cilindros	0000-00-00 - en adelante	-	-	OL462	-
TOYOTA	Land Cruisier	Land Cruisier Naftera 3,0, 3,2, 3,4	0000-00-00 - en adelante	-	-	OL462	-
TOYOTA	Land Cruisier	Land Cruisier TD 3.0	1996-04-01 - en adelante	AR2032	-	-	-
TOYOTA	Lift Truck	Lift Truck 7FGCU20	0000-00-00 - en adelante	AR2066	-	-	-
TOYOTA	Rav	4 2.0 D-4D 4WD 1CD FTV	2002-01-01 - en adelante	-	TH984	-	GS103

Marca	Modelo	Serie	Desde Hasta	Aire	Habitaculo	Aceite	Combustible
TOYOTA	Rav	4 2.0 D-4D Turbodies 1CD FTV	0000-00-00 - en adelante	-	TH984	-	-
TOYOTA	Rav 4	Naftera 2.0 Mpi	1997-01-01 - en adelante	-	TH984	OL501	-
TOYOTA	Rav 4	Naftera 4x2 1.8	2000-04-05 - en adelante	-	TH984	OL501	-
TOYOTA	Rav 4	RAV 4 III 2,0 VVTi	2000-04-05 - en adelante	AR1726PM	-	-	-
TOYOTA	Stallion	Stallion/TUV 1500 5K	2000-03-26 - en adelante	-	-	OL462	-
TOYOTA	Stout	Stout 5-A	0000-00-00 - en adelante	-	-	-	GS193