

Marca	Modelo	Serie	Desde Hasta	Aire	Habitaculo	Aceite	Combustible
DAIHATSU	Aplause	Aplause Xi 1,6ieMP 16V	0000-00-00 - en adelante				OL498
DAIHATSU	Applause	Aplause Carburador 1,6	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Applause	Applause 1.6i 16V	0000-00-00 - 1990-01-01 -		-		OL501 -
DAIHATSU	Charade	Charade SG 16V	0000-00-00 - 1989-01-01 -		-		OL501 -
DAIHATSU	Cuore (L201)	Cuore (L201) ED 10K 847 cc	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Cuore (L501)	Cuore (L501) ED 20 847 cc	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Delta	Delta Wide 2.0	0000-00-00 - en adelante -		-		- GS140
DAIHATSU	Delta	Delta Wide 1,6	0000-00-00 - en adelante -		-		- GS140
DAIHATSU	Delta	Delta Wide 3.7 Diesel	1997-01-01 - en adelante	AR2045	-		- -
DAIHATSU	Feroza	Feroza 4x4 Carburador 1.6	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Feroza	Feroza 4x4 Catalitico 1.6 16v	0000-00-00 - en adelante -		-		OL501 -
DAIHATSU	Hi-Jet	HI-jet VAN diesel 1,2	0000-00-00 - en adelante	AR1607PM	-		- -
DAIHATSU	Mira	Mira 989cc 12V	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Move Inyeccion	Move Inyeccion 847 cc	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	New Move	New Move 989cc 12V EJ	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Rocky	Rocky TDI 2,8	0000-00-00 - en adelante -		-		- GS139
DAIHATSU	Sirion (M100)	Sirion (M100) 1,0ieMP 12V	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Terios 4x4	Terios 4x4 1,3ieMP 16V/ 1,3ieMP 16V	0000-00-00 - en adelante -		-		OL498 -
DAIHATSU	Volcado	Camión Volcador	2000-01-01 - en adelante -		-		OL456 GS193
DAIHATSU	Wide	Wide Furgon, Van	0000-00-00 - en adelante -		-		- GS139