

Marca	Modelo	Serie	Desde Hasta	Aire	Habitaculo	Aceite	Combustible
LANCIA	Dedra	Dedra 1,8	1994-07-01 - 1999-07-01	AR208PM			
LANCIA	Dedra	Dedra 2,0, 2,0i 16V	1994-07-01 - 1996-07-01	AR208PM -	-	-	
LANCIA	Dedra	Dedra GT 1,8 16V	1994-07-01 - 1999-07-01	AR208PM -	-	-	
LANCIA	Dedra	Dedra LE 1,6	1994-09-01 - 1999-07-01	AR208PM -	-	-	
LANCIA	Delta	Delta GT 1,6	1982-11-01 - 1986-04-01	AR185PM -	-	-	
LANCIA	Delta	Delta GT 1,6i	1985-02-01 - 1991-12-01	AR185PM -	-	-	
LANCIA	Delta	Delta GT 1,8 16V	1993-05-01 - 1999-07-01	AR208PM -	-	-	
LANCIA	Delta	Delta HF turbo 1,6	1985-02-01 - 1991-12-01	AR185PM -	-	-	
LANCIA	Delta	Delta HF turbo integrale 2,0 16v	0000-00-00 - en adelante	AR185PM -	-	-	
LANCIA	Delta	Delta LE 1,6 16V	1996-01-01 - 1999-07-01	AR208PM -	-	-	
LANCIA	Delta	Delta LX 1,3	1979-09-01 - 1992-08-01	AR185PM -	-	-	
LANCIA	Delta	Delta Turbo 16V	1993-05-01 - 1999-07-01	AR208PM -	-	-	
LANCIA	Prisma	Prisma 1,3	1983-02-01 - 1988-09-01	AR185PM -	-	-	
LANCIA	Prisma	Prisma 1,5	1983-02-01 - 1988-09-01	AR185PM -	-	-	
LANCIA	Prisma	Prisma 1,6	1983-02-01 - 1988-09-01	AR185PM -	-	-	
LANCIA	Prisma	Prisma IE 4WE 2.0	1986-04-01 - 1989-12-01	AR185PM -	-	-	
LANCIA	Prisma	Prisma IE super 1,6	1983-02-01 - 1988-09-01	AR185PM -	-	-	
LANCIA	Ypsilon	Ypsilon JTD Multijet 16V 1,3	0000-00-00 - en adelante	-	EOL111	-	
LANCIA	Zeta	Zeta JTD 2.0	1999-01-01 - en adelante	AR234PM -	-	EGSO200	
LANCIA	Zeta	Zeta TD 1,9	1999-01-01 - en adelante	AR234PM -	-	-	
LANCIA	Zeta	Zeta TD 2,1	1996-07-01 - 1999-09-01	AR234PM -	-	-	