

Marca	Modelo	Serie	Desde Hasta	Aire	Habitaculo	Aceite	Combustible
ROVER - LANDROVER	114	114 GTI	1991-01-01 - en adelante	AR464PM			
ROVER - LANDROVER	115	115 SD GLS Diesel 1,4i	0000-00-00 - en adelante	-	-	-	GS130
ROVER - LANDROVER	211	211	1998-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	211	211	1998-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	214	214	0000-00-00 - en adelante	AR464PM -	-	-	
ROVER - LANDROVER	214	214 Si, SLi 1.4i	0000-00-00 - en adelante	AR464PM -	OL496	-	
ROVER - LANDROVER	216	216 Gsi 16v, 1.6 Si 16V	0000-00-00 - en adelante	AR1610PM -	OL496	-	
ROVER - LANDROVER	218	218 1,8	1993-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	218	218 1,8	0000-00-00 - en adelante	AR464PM -	-	-	
ROVER - LANDROVER	218	218 1.8 D / TD / GSD	1992-07-01 - en adelante	AR1670PM -	EOL144	GSO440	
ROVER - LANDROVER	220	220 Coupé 2.0i	0000-00-00 - en adelante	AR464PM -	OL485	-	
ROVER - LANDROVER	220	220 DI SDI - D SD	0000-00-00 - en adelante	-	OL485	-	
ROVER - LANDROVER	220	220 GTI	1993-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	220	220 turbo	1993-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	25	25 1,4i 16V	2000-01-01 - en adelante	AR1610PM -	OL496	-	
ROVER - LANDROVER	25	25 1,6i 16V HP 80	2000-01-01 - en adelante	AR1610PM -	OL496	-	
ROVER - LANDROVER	25	25 1,8i 16V	2000-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	414	414 GSI 1.4i	1990-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	414	414 SLi 1.4i	0000-00-00 - en adelante	AR464PM -	OL496	-	
ROVER - LANDROVER	416	416 Si 1.6i	1996-04-01 - en adelante	AR1610PM -	OL496	-	
ROVER - LANDROVER	416	416 Si 1.6 16V Automatico	1995-05-01 - en adelante	AR1617PM -	OL496	-	
ROVER - LANDROVER	420	420 GSI , turbo, SLI, VITESSE 1.4i	1993-01-01 - en adelante	AR1610PM TH950	-	-	
ROVER - LANDROVER	420	420 Sli 2.0i	0000-00-00 - en adelante	AR464PM TH950	OL485	-	
ROVER - LANDROVER	420	420 Sli 2.0i 16V	0000-00-00 - en adelante	AR464PM TH950	OL496	-	
ROVER - LANDROVER	45	45 1.8 16V K 1.8, 2.0 V6 KV6	2000-01-02 - en adelante	-	OL496	-	
ROVER - LANDROVER	620	620 SLDi 2.0i	0000-00-00 - en adelante	AR1610PM THC949	OL485	GS66	
ROVER - LANDROVER	75	75 2.0 V6 KV6 HP 110 SI 2.0i	1999-01-04 - en adelante	-	OL495	-	
ROVER - LANDROVER	75	75 1.8 K HP 88	1999-01-04 - en adelante	-	OL496	-	
ROVER - LANDROVER	75	75 RC, CDT 2.0	1999-01-04 - en adelante	AR2132 -	EOL125	-	
ROVER - LANDROVER	820	820 2,0i SI	1992-01-01 - en adelante	AR1614PM -	-	-	
ROVER - LANDROVER	820	820 2,0i SI-se	1986-10-01 - 1991-12-01	AR1614PM -	OL496	IN1004	
ROVER - LANDROVER	820	820 Ti 2.0i	0000-00-00 - en adelante	AR464PM -	OL485	-	
ROVER - LANDROVER	820	820 Ti 2.0i	0000-00-00 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	Defender	Defender	0000-00-00 - en adelante	AR1470 -	OL161	-	
ROVER - LANDROVER	Defender	Defender 2,5 TDI 11L 200Tdi	1990-09-01 - 1995-09-01	AR2072 -	-	-	
ROVER - LANDROVER	Defender	Defender 2,5 TDI	0000-00-00 - en adelante	AR1470 -	-	-	
ROVER - LANDROVER	Defender	Defender 110 TDI 4 x 4 2.5	0000-00-00 - en adelante	AR1614PM -	OL58	GS66	
ROVER - LANDROVER	Defender	Defender 300	0000-00-00 - en adelante	AR1470 -	-	-	
ROVER - LANDROVER	Defender	Defender 300 TDI 4 x 4	0000-00-00 - en adelante	AR1614PM -	OL460	GS66	
ROVER - LANDROVER	Defender	Defender 90 3,5 L	0000-00-00 - en adelante	-	OL58	-	
ROVER - LANDROVER	Discovery	Discovery 200 TDI	0000-00-00 - en adelante	AR2072 -	OL58	GS66	
ROVER - LANDROVER	Discovery	Discovery 300 TDI	0000-00-00 - en adelante	-	OL58	GS66	
ROVER - LANDROVER	Freelander	Freelander TD4 2.0 TD4	2000-01-01 - en adelante	AR2132 -	EOL125	-	
ROVER - LANDROVER	Freelander	Freelander XEdi Turbo intercooler 2.0 Tdi 8V	1997-12-01 - en adelante	AR1610PM -	EOL125	-	
ROVER - LANDROVER	Freelander	Freelander XEi 1.8 Mpie 16V	1997-12-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	Maestro	Maestro Diesel 1,4	0000-00-00 - en adelante	AR363 -	OL58	GS97	
ROVER - LANDROVER	Metro	Metro 1,4 GTI	1991-01-01 - en adelante	AR1610PM -	-	-	
ROVER - LANDROVER	Range Rover	Range Classic (Desde Serie LA 647645)	0000-00-00 - en adelante	-	-	GS66	
ROVER - LANDROVER	Range Rover	Range Classic (Hasta Serie LA 647644)	0000-00-00 - en adelante	-	-	GS66	
ROVER - LANDROVER	Range Rover	Range Rover SE Naftero 4,0 V8i	1994-10-01 - en adelante	-	OL460	IN88	
ROVER - LANDROVER	Range Rover	Range Rover TD VM 2.5	0000-00-00 - en adelante	AR1614PM TH965	OL58	GS66	
ROVER - LANDROVER	Range Rover	Range Rover TDI 2.5	1996-06-01 - en adelante	-	EOL120	-	
ROVER - LANDROVER	Range Rover	Range Rover TDI 2.5	0000-00-00 - en adelante	AR1614PM TH965	OL58	GS66	
ROVER - LANDROVER	Range Rover	Range Rover TDI 3.0 TD V6	2002-01-01 - 2006-01-01	AR2131 TH965	-	-	
ROVER - LANDROVER	Range Rover	Range Rover TDI / TD 2.5	1996-06-01 - en adelante	AR2072 -	-	-	